Digital Signals Control systems and Computer Networks

Dr Alun Moon

Lecture 1.2

	//		200
171	AILIII	1010	лоп

→ Ξ →

A Digital Signal is:

イロト イヨト イヨト イヨト

A Digital Signal is:

True

D	A 1		N /		
Dr	AI	un	IV	0	on

イロト イヨト イヨト イヨト

A Digital Signal is:

True False

A Digital Signal is:

True False

A Digital Signal is:

True False 1 0

A Digital Signal is:

True False 1 0 on

A Digital Signal is:

True	False
1	0
on	off

D	A 1		N /		
Dr	AI	un	IV	0	on

イロト イヨト イヨト イヨト

A Digital Signal is:

True	False
1	0
on	off
Pressed	

D	Λ		Ν/		~ ~
	А	iuii	10	10	UI.

∃ →

(日)

A Digital Signal is:

True False 1 0 off on Pressed Not-pressed

A B A A B A

A Digital Signal is:

True False 1 0 off on Pressed Not-pressed High

∃ →

→ Ξ →

A Digital Signal is:

True False 1 0 off on Pressed Not-pressed High Low

∃ →

→ Ξ →

- (日)

A Digital Signal is:

True False 1 0 off on Pressed Not-pressed High Low 5 V

∃ →

• = • •

- (日)

A Digital Signal is:

True False 1 0 off on Pressed Not-pressed High Low 5 V 0 V

∃ →

• = • •

< 行

A Digital Signal is:

TrueFalse10onoffPressedNot-pressedHighLow5 V0 V3.3 V

() < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < () < ()

< 行

A Digital Signal is:

True	False
1	0
on	off
Pressed	Not-pressed
High	Low
5 V	0 V
3.3 V	0 V

イロト イヨト イヨト イヨト

A Digital Signal is:

TrueFalse10onoffPressedNot-pressedHighLow5 V0 V3.3 V0 V

from a software perspective anything convenient for us to use

< 3 >

A Digital Signal is:

TrueFalse10onoffPressedNot-pressedHighLow5 V0 V3.3 V0 V

from a software perspective anything convenient for us to use

there are external limitations and constraints,

A Digital Signal is:

TrueFalse10onoffPressedNot-pressedHighLow5 V0 V3.3 V0 V

from a software perspective anything convenient for us to use

- there are external limitations and constraints,
 - Physics

< ∃ > <

A Digital Signal is:

TrueFalse10onoffPressedNot-pressedHighLow5 V0 V3.3 V0 V

from a software perspective anything convenient for us to use

- there are external limitations and constraints,
 - Physics
 - Standards

< ∃ ▶

Electrical Characteristics

Generally : positive voltage logical 1 negative voltage logical 0

< □ > < 同 > < 回 > < 回 > < 回 >

Generally : positive voltage logical 1 negative voltage logical 0

Specific technologies have specific voltages for *on* TTL Transistor Transistor Logic 5V CMOS Complementary Metal Oxide Semiconductor 3.3V

• = • •



イロト イヨト イヨト イヨト



► Traffic Lights

イロト イヨト イヨト イヨト



- Traffic Lights
 - Red \rightarrow Red,Amber \rightarrow Green \rightarrow Amber \rightarrow Red ...

< □ > < 同 > < 回 > < 回 > < 回 >



- Traffic Lights
 - Red \rightarrow Red,Amber \rightarrow Green \rightarrow Amber \rightarrow Red ...
 - $\langle \{r\}, \{r, a\}, \{g\}, \{a\} \rangle$

< □ > < 同 > < 回 > < 回 > < 回 >



- Traffic Lights
 - Red \rightarrow Red,Amber \rightarrow Green \rightarrow Amber \rightarrow Red ...
 - $\langle \{r\}, \{r, a\}, \{g\}, \{a\} \rangle$
 - Can be written as a Timing Diagram



A B b A B b



- Traffic Lights
 - Red \rightarrow Red,Amber \rightarrow Green \rightarrow Amber \rightarrow Red ...
 - $\langle \{r\}, \{r, a\}, \{g\}, \{a\} \rangle$
 - Can be written as a Timing Diagram



Flashing

A B A A B A



- Traffic Lights
 - Red \rightarrow Red,Amber \rightarrow Green \rightarrow Amber \rightarrow Red ...
 - $\langle \{r\}, \{r, a\}, \{g\}, \{a\} \rangle$
 - Can be written as a Timing Diagram



- Flashing
 - $On \rightarrow Off \rightarrow On \ldots$

★ ∃ ► ★



- Traffic Lights
 - Red \rightarrow Red,Amber \rightarrow Green \rightarrow Amber \rightarrow Red ...
 - $\langle \{r\}, \{r, a\}, \{g\}, \{a\} \rangle$
 - Can be written as a Timing Diagram



- Flashing
 - $On \rightarrow Off \rightarrow On \ldots$
 - ¬_____

→ Ξ →

Digital IO from the μ C

Microcontrollers (μ C) have dedicated hardware for digital IO.

- The K64F has 5 ports with 32 IO pins which can be used as GPIO pins (General Purpose Input Output)
- The IO circuit has a number of configureable options for each pin, accessed through several registers
- ► ALL the appropriate bits need to be set or it doesn't work.

- B - - B

GPIO Hardware Registers

Sequence and purpose of bits to set

There are several bits to set to configure the pin

- System Clock Gating Control Register SCGC Enables the clock signal for the port, making it function
- Pin Control Register PORTx_PCRn
 a 32bit register for each pin setting several options
 - IRQC Interrupt configuration (what causes an interrupt to occur)
 - MUX Pins have multiple functions, this selects the function to use.
 - DSE Drive Strength, the electrical characteristics of the output
 - ODE Open Drain, elctrical connections of the Output
 - PFE Passive Filter for inputs (debounce and glitch rejection)
 - SLE Slew Rate, how fast the output switches between high and Low
 - PE enable pull up or down resistor for inputs
 - PS selects the pull-up or pull-down resistor.

ヘロア 人間 アメヨア ション

GPIO Hardware Registers

Port Registers

Each Port has several registers to use for the actual IO operations. Each bit in the register corresponds to an external pin.

GPIOx_PDOR Port Data Output Register

- 0. Set the output to logic 0
- $1. \ \mbox{Set}$ the output to logic 1

GPIOx_PSOR Port Set Output Register

- 0. output does not change
- 1. Set the output to logic 1

GPIOx_PCOR Port Clear Output Register

- 0. output does not change
- 1. Set the output to logic 0

GPIOx_PTOR Port Toggle Output Register

- 0. Output does not change
- 1. Change the logic state of the output

GPIO Hardware Registers

Port Registers

GPIOx_PDIR Port Data Input Register 0. Pin is set to input logic 0 (or is not configured) 1. Pin is set ti input logic 1

GPIOx_PDDR Port Data Direction Register

- 0. GPIO pin set as input
- 1. GPIO pin set as output

A B A A B A

- The μ C pin is set to 0 or 1
- \blacktriangleright in the case of the K64F $1\equiv3.3\,\text{V}$
- But what does that do?
- It depends on the external circuit.



- The μ C pin is set to 0 or 1
- \blacktriangleright in the case of the K64F $1\equiv3.3\,\text{V}$
- But what does that do?
- It depends on the external circuit.



- The μ C pin is set to 0 or 1
- \blacktriangleright in the case of the K64F $1\equiv3.3\,\text{V}$
- But what does that do?
- It depends on the external circuit.



- The μ C pin is set to 0 or 1
- \blacktriangleright in the case of the K64F $1\equiv3.3\,\text{V}$
- But what does that do?
- It depends on the external circuit.



- The μ C pin is set to 0 or 1
- in the case of the K64F $1 \equiv 3.3$ V
- But what does that do?
- It depends on the external circuit.



Input

- The μ C pin is set to 0 or 1 by the external circuit
- But what does that mean?
- It depends on the external circuit.



Input

- The μ C pin is set to 0 or 1 by the external circuit
- But what does that mean?
- It depends on the external circuit.





→ Ξ →

Image: Image:

10 Circuits

Input

₼

- The μC pin is set to 0 or 1 by the external circuit
- But what does that mean?
- It depends on the external circuit.

Base Shield Push Buttons

Not Pressed pin is 3.3 V connected to 3.3V (logic 1) through *pull-up* resistor pin

Pressed pin is shorted to 0V (logic 0)

Upper Shield 5-way switch

Not Pressed pin is connected to 0 V (logic 0) through pull-down resistor

3.3 V

pin

< □ > < 凸

Input

- The μ C pin is set to 0 or 1 by the external circuit
- But what does that mean?
- It depends on the external circuit.

Base Shield Push Buttons

3.3∨ ↓ pin

Not Pressed pin is connected to 3.3 V (logic 1) through pull-up resistor

 Pressed pin is shorted to 0 V (logic 0)

Upper Shield 5-way switch

- Not Pressed pin is connected to 0 V (logic 0) through pull-down resistor
- Pressed pin is shorted to 3.3 V (logic 1)

< □ > < □ > < □ > < □ > < □ > < □ >

3.3 V

pin

Some Mathematics

- Digital signals are logic values
- Can be modelled using discrete maths and Boolean Algebra.
- We need a new notation to indicate the change in state

Definition (Change in state)

The new state is indicated by the use of a prime.

 $a' = a \oplus 1$

The digital signal a has a new value a', the XOR of the current state and 1

What does this do?



• A sequence can be written in a manner similar to a set:

 $\langle \{r\}, \{r,a\}, \{g\}, \{a\}, \{r\}\rangle$

• • = • •



• A sequence can be written in a manner similar to a set:

$$\langle \{r\}, \{r, a\}, \{g\}, \{a\}, \{r\} \rangle$$

Expressing the change in state as a function of other states:

$$r' = \neg r \lor g \lor b$$

recursively in this case

→ Ξ →



• A sequence can be written in a manner similar to a set:

$$\langle \{r\}, \{r, a\}, \{g\}, \{a\}, \{r\} \rangle$$

Expressing the change in state as a function of other states:

$$r' = \neg r \lor g \lor b$$

recursively in this case

Iteratively:

$$b_n = n \in \mathbb{Z}_{\text{primes}}$$

 $g_{n+1} = B_1 \Rightarrow g_n \oplus 1$

Now we have an understanding of:

- What a digital signal is
- How to manipulate them

We have a question:

What should the signal be? How should it behave?

This is where constraints from the application domain, and any applicable standards, dictate the operation.

For a 2-way junction we have 2 sets of Lights.

 r_n,a_n,g_n,r_w,a_w,g_w

D	Λ Ι		N /		• •
Dr	A	un	IV	юc	л

For a 2-way junction we have 2 sets of Lights.

 $r_n, a_n, g_n, r_w, a_w, g_w$

6 bits $2^6 = 64$ possible combinations

• • = • •

For a 2-way junction we have 2 sets of Lights.

 r_n,a_n,g_n,r_w,a_w,g_w

- 6 bits $2^6 = 64$ possible combinations
 - What combinations are allowed?

For a 2-way junction we have 2 sets of Lights.

 r_n,a_n,g_n,r_w,a_w,g_w

6 bits $2^6 = 64$ possible combinations

- What combinations are allowed?
- What are the allowed transitions?

Morse Code

- Morse code is a Digital signal (on and off)
- ► The sequence of states and their timing is defined by standards International Morse code Recommendation ITU-R M.1677-1

Timing

- 1. short mark, dot or "dit" : "dot duration" is one time unit long
- 2. longer mark, dash or "dah": three time units long
- 3. inter-element gap between the dots and dashes within a character: one dot duration or one unit long
- 4. short gap (between letters): three time units long
- 5. medium gap (between words): seven time units long

Two Handed start

- In many industrial automation environments "two-handed" start is used as a safety feature
- to start a machine, two start switches, must be pressed together, in order to start.

Logic	
m b ₁ b ₂	state of motor one start switch second start switch
Constraint	$b_1 \wedge b_2 \Rightarrow m$
Action	$m'=m\vee(b_1\wedge b_2)$

Pullup and pulldown resistors

- ► In a number of places pull-up and pull-down resistors are mentioned.
- The problem occurs when a wire/pin has no input driving it, what logic value does it have? o----o--o--

Pull-up resistor

Pull-up resistor connects the pin to the supply (logic 1) ensuring a 1 when there is no other signal.

Pull-down resistor

Pull-down resistor connects the pin to the ground (logic 0) ensuring a 0 when there is no other signal.